

KEY FOB PROGRAMMING INSTRUCTIONS

FOR AUTOMOBILES:

These vehicles can be programmed using the instructions below:

- 2001-2004 Chevrolet Corvette

These vehicles require the use of a professional scan tool for programming (see your local GM dealer or ACDelco Professional Service Center):

- 2001-2005 Buick LeSabre
 - 2001-2005 Cadillac DeVille
 - 2004-2005 Chevrolet Classic
 - 2001-2003 Chevrolet Malibu
 - 2001-2004 Oldsmobile Alero
 - 2001-2003 Oldsmobile Aurora
 - 2001-2005 Pontiac Bonneville
 - 2001-2005 Pontiac Grand Am
-

PROGRAMMING INSTRUCTIONS:

1. Turn the ignition key to ON.
 2. Clear any warning messages on the Driver Information Center (DIC) by pressing the RESET button.
 3. Press the OPTIONS button on the DIC several times until the blank page is displayed, then press and hold the RESET button for two seconds.
 4. When the message FOB TRAINING is displayed, press the RESET button once. The message HOLD LK + UNLK 1ST FOB will be displayed in the DIC.
 5. Press and hold the lock and unlock buttons on the first transmitter simultaneously for five seconds.
 6. When a transmitter is learned (matched), the DIC will display FOB LEARNED and then prompt you to learn the second transmitter.
 7. Repeat Steps 5 and 6 for the third transmitter.
 8. Remove the key from the ignition.
-