

KEY FOB PROGRAMMING INSTRUCTIONS - 25678792

FOR AUTOMOBILES:

These vehicles can be programmed using the instructions below:

- 2000 Chevrolet Malibu
- 2000 Oldsmobile Alero
- 2000 Pontiac Grand Am

These vehicles require the use of a professional scan tool for programming (see your local GM dealer or ACDelco Professional Service Center):

- 1996-1999 Buick LeSabre
- 1996-1998 Buick Park Avenue
- 1996-1999 Buick Riviera
- 2000-2000 Chevrolet Impala
- 2000-2000 Chevrolet Monte Carlo
- 1996-1999 Oldsmobile 88
- 1996-1996 Oldsmobile 98
- 1999 Oldsmobile Alero
- 1996-1999 Oldsmobile Aurora
- 1996-1999 Oldsmobile LSS
- 1997-1998 Oldsmobile Regency
- 1996-1999 Pontiac Bonneville
- 1999 Pontiac Grand Am

TO PROGRAM 2000 CHEVROLET MALIBU, 2000 PONTIAC GRAND AM, AND 2000 OLDSMOBILE ALERO:

1. Close all the vehicle doors.
2. Remove the ignition key from the ignition lock cylinder.

▲ IMPORTANT: IN ORDER TO SUCCESSFULLY ENTER THE KEYLESS ENTRY PROGRAMMING/DIAGNOSTIC MODE, YOU MUST COMPLETE STEPS 4-6 WITHIN 25 SECONDS OF PRESSING THE DOOR UNLOCK SWITCH.

3. Press and hold the door unlock switch.
4. While holding the door lock switch in the unlock position, insert and remove the ignition key twice. Do not rotate the ignition lock cylinder.
5. Insert the ignition key a third time leaving the key in the ignition lock cylinder. Keep the ignition in the LOCK position for the rest of the procedure.
6. Release the door lock switch. The chime will sound 3 chimes, which signals that the transmitter programming/diagnostic mode is active.
7. Press and hold the lock and unlock buttons at the same time on the keyless entry transmitter for approximately 4 seconds. The chime will sound two times which signals that the transmitter has been programmed successfully.
8. Repeat step 7 for each of the four transmitters.
9. Perform either of the following final procedures:
 - Turn the ignition switch to the RUN position.
 - Remove the ignition key from the ignition switch.