ACDelco

KEY FOB PROGRAMMING INSTRUCTIONS - 20935331

FOR AUTOMOBILES:

These vehicles can be programmed using the instructions below:

- 2006-2010 Buick Lucerne
- 2006-2007 Cadillac DTS
- 2006-2010 Chevrolet Impala
- 2006-2007 Chevrolet Monte Carlo

These vehicles require the use of a professional scan tool for programming (see your local GM dealer or ACDelco Professional Service Center):

- 2011 Buick Lucerne
- 2007-2010 Chevrolet Cobalt
- 2011-2013 Chevrolet Impala
- 2014-2014 Chevrolet Impala Limited
- 2007-2010 Pontiac G5
- 2007-2008 Pontiac G6
- 2007-2008 Saturn Aura
- 2010 Saturn Sky

PROGRAMMING INSTRUCTIONS

This procedure will erase all previously learned transmitters. Therefore, they must be relearned as additional transmitters.

1. Press the vehicle information button 🚗i until PRESS ✓ TO RE-LEARN REMOTE KEY displays.

2. Press the set/reset button until REMOTE KEY LEARNING ACTIVE is displayed.

3. Press and hold the lock and unlock buttons on the first transmitter at the same time for about 15 seconds. A chime will sound indicating that the transmitter is matched.

4. To match additional transmitters at this time, repeat Step 3. Each vehicle can have a maximum of eight transmitters matched to it.

5. To exit the programming mode, you must cycle the key to LOCK/OFF.