

INSTALLATION INSTRUCTIONS FOR SWAY BAR TO LOWER CONTROL ARM BUSHING KIT

- 1. Remove sway bar clamps from bushings on lower control arms, and slide bushings off ends of sway bar.**
- 2. Slip new bushings supplied over ends of sway bar and into position on lower control arms.**
- 3. Install original clamps on bushings using original bolts, lock washers, and nuts to secure sway bar and bushings to lower arms. Torque nuts or bolts to 40 foot pounds.**

© COPYRIGHT 1985 / ISSUED SEPTEMBER, 1985 / LITHO U.S.A.

Form 2711

Form 2711

INSTRUCTIONS POUR L'INSTALLATION DE LA BARRE OSCILLANTE SUR LE MONTAGE DE BAGUES DU BRAS DE COMMANDE INFÉRIEUR

- 1.** Enlevez les colliers de la barre oscillante des bagues des bras de commande inférieurs, et enlevez les bagues en les faisant glisser jusqu'à chacun des bouts de la barre oscillante.
- 2.** Faites passer les nouvelles bagues fournies par les extrémités de la barre oscillante et placez-les sur les bras de commande inférieurs.
- 3.** Installez les colliers d'origine sur les bagues à l'aide des boulons, bagues d'arrêt et écrous d'origine pour fixer la barre oscillante et les bagues aux bras inférieurs. Serrez les écrous ou boulons selon un couple de 40 lb.pi.