

CAUTION

Clean dirt or grease away from area around bushing flange on control arm, and inspect for flange being tack welded to arm. If welded, break weld with a sharp hand chisel and hammer, being careful not to distort arm. Use a spacer sleeve between sides of arm to help support flange when cutting weld, and during bushing removal and installation.

© COPYRIGHT 1985 / ISSUED SEPTEMBER, 1985 / LITHO U.S.A.

ATTENTION

Nettoyez les saletés et la graisse des parties proches des rebords des bagues sur le bras de commande, et examinez le rebord pour voir s'il n'est pas soudé par points au bras. S'il est soudé, faites sauter la soudure à l'aide d'un burin à main bien tranchant et d'un marteau, en prenant garde de ne pas tordre le bras. Utilisez un manchon d'écartement entre les extrémités du bras pour supporter le rebord pendant que vous coupez la soudure et pendant le démontage des bagues et leur installation.