



## WAGNER BRAKE EDGE CODE IDENTIFIER EXAMPLES



Wagner® OEX edge codes are laser etched onto shim.

Edge code begins with WGN\*\*\*\*



Wagner TQ® edge codes are etched directly onto back plate or shim.

Edge code begins with TQ\*\*\* or FM\*\*\*



Wagner SD™ edge codes are etched onto side of friction.

Edge code begins with WAGSX\*\*\* or FM\*\*\*



## WAGNER BRAKE EDGE CODE IDENTIFIER EXAMPLES



Wagner QS™ edge codes are etched onto shim.

Edge code begins with QS\*\*\* or WAG\*\*\*



Wagner® shoe edge codes are etched directly onto shoe.

Edge code begins with WE\*\*\*



WagnerBrake.com

© 2020 DRiV Automotive Inc. or one of its affiliates in one or more countries. WB201270