

KEY FOB PROGRAMMING INSTRUCTIONS - 20869056

FOR AUTOMOBILES:

These vehicles can be programmed using the instructions below:

- 2008-2008 Buick Enclave
- 2007-2009 Cadillac Escalade EXT
- 2007-2010 Chevrolet Avalanche
- 2007-2009 Chevrolet Equinox
- 2008-2010 Chevrolet Express 3500
- 2007-2010 Chevrolet Silverado 1500
- 2007-2010 Chevrolet Silverado 2500 HD
- 2007-2010 Chevrolet Silverado 3500 HD
- 2007-2010 GMC Acadia
- 2008-2010 GMC Savana 3500
- 2007-2010 GMC Sierra 1500
- 2007-2010 GMC Sierra 2500 HD
- 2007-2010 GMC Sierra 3500 HD
- 2007-2009 Pontiac Torrent
- 2007-2010 Saturn Outlook
- 2009-2010 Saturn Vue


These vehicles require the use of a professional scan tool for programming (see your local GM dealer or ACDelco Professional Service Center):

- 2011 Chevrolet Avalanche
- 2011-2014 Chevrolet Express 3500
- 2011-2014 Chevrolet Express 4500
- 2011-2013 Chevrolet Silverado 1500
- 2011-2014 Chevrolet Silverado 2500 HD
- 2011-2014 Chevrolet Silverado 3500 HD
- 2011-2014 GMC Savana 3500
- 2011-2014 GMC Savana 4500
- 2011-2013 GMC Sierra 1500
- 2011-2014 GMC Sierra 2500 HD
- 2011-2014 GMC Sierra 3500 HD
- 2008 Saturn Vue

PROGRAMMING INSTRUCTIONS

This procedure will erase all previously learned transmitters. Therefore, they must be relearned as additional transmitters.

FOR VEHICLES WITH DRIVER INFORMATION CENTER (DIC):

1. Press the vehicle information button  until PRESS ✓ TO RE-LEARN REMOTE KEY displays.
2. Press the set/reset button until REMOTE KEY LEARNING ACTIVE is displayed.
3. Press and hold the lock and unlock buttons on the first transmitter at the same time for about 15 seconds.

On vehicles with memory recall seats, the first transmitter learned will match driver 1 and the second will match driver 2. A chime will sound indicating that the transmitter is matched.

4. To match additional transmitters at this time, repeat Step 3.
5. To exit the programming mode, you must cycle the key to LOCK/OFF.

FOR VEHICLES WITHOUT DRIVER INFORMATION CENTER (DIC):

To access this display, the vehicle must be in PARK (P).

1. Press the trip odometer reset stem until RELEARN REMOTE KEY displays.
2. Press and hold the trip odometer reset stem for three seconds. The message REMOTE KEY LEARNING ACTIVE will display.

3. Press and hold the lock and unlock buttons on the first transmitter at the same time for about 15 seconds. On vehicles with memory recall seats, the first transmitter learned will match driver 1 and the second will match driver 2. A chime will sound indicating that the transmitter is matched.
4. To match additional transmitters at this time, repeat Step 3.
5. To exit the programming mode, you must cycle the key to LOCK.

2007 SILVERADO CLASSIC AND SIERRA CLASSIC:

1. Close all the vehicle doors.
2. Insert the ignition key into the ignition lock cylinder.
3. Press and hold the door unlock switch.
4. While holding the door lock switch in the unlock position, cycle the ignition ON, OFF, ON, OFF.
5. Release the door unlock switch. The doors will lock and unlock to confirm the program mode.
6. Press and hold the LOCK button and the UNLOCK button simultaneously on one transmitter. After a delay of approximately 15 seconds, the doors will lock and unlock to confirm the programming of that transmitter.
7. Repeat the previous step to program up to 4 transmitters.
8. Turn the ignition switch to the RUN position in order to exit the keyless entry transmitter programming mode.
9. Operate the transmitter functions in order to verify correct system operation.