KEY FOB PROGRAMMING INSTRUCTIONS - 15042968

FOR AUTOMOBILES:
These vehicles can be programmed using the instructions below:

- 2002 Cadillac Escalade
- 2002 Cadillac Escalade EXT
- 2002 Chevrolet Avalanche 1500
- 2002 Chevrolet Avalanche 2500
- 2001-2004 Chevrolet S10
- 2001-2002 Chevrolet Silverado 1500
- 2001-2002 Chevrolet Silverado 1500 HD
- 2001-2002 Chevrolet Silverado 2500
- 2001-2002 Chevrolet Silverado 2500 HD
- 2001-2002 Chevrolet Silverado 3500
- 2001-2002 Chevrolet Suburban 1500
- 2001-2002 Chevrolet Suburban 2500
- 2001-2002 Chevrolet Tahoe
- 2001-2002 GMC Sierra 1500
- 2001-2002 GMC Sierra 1500 HD
- 2001-2002 GMC Sierra 2500
- 2001-2002 GMC Sierra 2500 HD
- 2001-2002 GMC Sierra 3500
- 2001 GMC Sierra C3
- 2001-2004 GMC Sonoma
- 2001-2002 GMC Yukon
- 2001-2002 GMC Yukon XL 1500
- 2001-2002 GMC Yukon XL 2500

These vehicles require the use of a professional scan tool for programming (see your local GM dealer or ACDelco Professional Service Center):

- 2005 Chevrolet Astro
- 2005 GMC Safari

PROGRAMMING INSTRUCTIONS

This procedure will erase all previously learned transmitters. Therefore, they must be relearned as additional transmitters.

You may program up to 4 transmitters, using the following procedure:

1. Close all the vehicle doors.

2. Insert the ignition key into the ignition lock cylinder.

3. Press and hold the door unlock switch.

4. While holding the door lock switch in the unlock position, cycle the ignition ON, OFF, ON, OFF.

5. Release the door unlock switch. The doors will lock and unlock to confirm the program mode.

6. Press and hold the LOCK button and the UNLOCK button simultaneously on one transmitter. After a delay of approximately 15 seconds, the doors will lock and unlock to confirm the programming of that transmitter.

7. Repeat the previous step to program up to four transmitters.

8. Turn the ignition switch to the RUN position in order to exit the keyless entry transmitter mode.

9. Operate the transmitter functions in order to verify correct system operation.